

## Kenwood fitting Guide for U.150452

### Wiring Colour Codes

Wire Colour	Function
Yellow	Permanent 12V
Black	Ground
Red	12V Ignition

Wire Colour	Function
Purple	Right Rear Speaker +
Purple/Black	Right Rear Speaker -
Green	Left Rear Speaker +
Green/Black	Left Rear Speaker -
Grey	Right Front Speaker +
Grey/Black	Right Front Speaker -
White	Left Front Speaker +
White/Black	Left Front Speaker -

### Fitting guide:

1. Remove and disconnect the original head unit.
2. Connect the patch lead to the black box



3. Connect the end of the patch lead to the Blue/yellow cable from the Kenwood loom. This will be marked "remote cont/steering wheel remote input"
4. Connect the 14 way molex connector to the interface.
5. Connect the male power/speaker ISO harness to the female power/speaker ISO harness from the Kenwood head unit.



Fit Kenwood head unit and connect up. Test head unit for operation.

### Controls:

1. Volume +/-
2. Mute
3. Track +/-

